



IGNITION OUTPUT
SEE IGNITION DRAWING

IGNITION INPUT
SEE IGNITION DRAWING

MTX-12 V8 PIN-OUTS

IGN OUTPUT (A)	IGN OUTPUT (B)	IGN OUTPUT (C)	IGN SPARE	IGN SPARE	IGN OUTPUT (D)
INJ BANK #4	INJ BANK #3	INJ BANK #2	INJ BANK #1	FUEL PUMP	WATER TEMP
AUX OUTPUT	TACH OUTPUT	INJ AUX #1	INJ AUX #2	T. P. S. +5V	T. P. S. S1B
AUX INPUT	MAP SENSOR	SPARE	GND	IGN +12V	OXYGEN SENSOR
POWER (RED)	GND (BLACK)	(GREEN X8)	CRANK INP 2	(WHITE X1)	CRANK INP 1

N.B.
USE ONLY ONE INJECTOR BANK PER INJECTOR BANK
1 X 2 OHM INJECTORS
2 X 2 OHM INJECTORS
4 X 12 OHM INJECTORS

MTX-12	8	DIRECT FIRE
Size	8	CYL
Part No.	8	REV. 1.0
Part No.	8	REV. 1.0
Part No.	8	REV. 1.0